

675 AND 676 SEMI-CONCEALED WARDROBE INSTALLATION INSTRUCTIONS

TOOLS REQUIRED FOR INSTALLATION: #2 Phillips screwdriver, small level

1. Attach the hangrod to the upper shelf (shelf with hangrod brackets) using #10-32 x 3/8" thread cutting screws (included).
2. Using the pre-started screws, attach the lower shelf (shelf without hangrod brackets) to the base brackets (brackets with leg and hook).
3. Attach the upper shelf in the same way as the lower shelf.
4. With the laminated panel laying on a clean, flat surface, attach the lower shelf assembly to the panel. Locate the bracket on the pre-drilled holes in the panel. The bottom edge of the panel rests in the hooks of the bottom bracket assembly. Use #10 x 3/4" screws.
5. With the hang rod facing toward the lower shelf assembly, mount the upper shelf assembly in the same way.
6. Carefully stand panel, with brackets attached, against the wall. Level as necessary, and attach to the wall with sixteen #12 x 2 1/2" screws (provided).

For assembly assistance, please call
1-866-217-0330.

